

When using the flue gas hose (e.g. in a cellar for conducting the flue gas outside through a window), the following must be observed

make sure that no condensate remains in the hose and clogs it.

If a „U-/Swan neck“ is formed (see illustration), it is essential that the condensate is drained off by means of an Ensure condensate drain (Art. No. 075361) in a container prefilled with liquid.

Exhaust gas must not escape into the room.

Irrespective of this, it must be ensured that the room is sufficiently ventilated.

